





SAFE-T-STRAP




BOX




FORM

1. UNROLL SAFE-T STRAP PARTIALLY
2. PLACE HALF ROLLED SAFE-T STRAP ON THE UNDERSIDE (INSIDE) OF BOX FASTEN BOX TO FLOOR FORM




BEFORE CONCRETE POURED IN



AFTER CONCRETE POURED IN

5# REBAR (5/8") MUST BE MINIMUM 8" LENGTH
 MINIMUM 3" DISTANCE
 POURED CONCRETE

3. TAKE A #5 (5/8") REBAR DOWEL AT LEAST 8" LONG AND PLACE THROUGH LOOP
4. WIRE INTO EXISTING REBAR, INSURING A MINIMUM 3" INBEDMENT



5. WHEN FORM IS REMOVED THE STRAP WILL DROP DOWN SAFETY STRAP IS LEFT FOR ANCHORAGE
- 6.



REV.	DESCRIPTION	DATE	BY	CHK.	APP.
1	LAYOUT REVISED	10/31/11	R.B.	R.B.	
0	ISSUED FOR REVIEW	10/28/11	S.W.	S.W.	

THE INFORMATION CONTAINED HEREIN IS PREPARED TO MEET THE REQUIREMENTS OF THE CLIENT AND IS NOT TO BE USED FOR ANY OTHER PURPOSES WITHOUT THE WRITTEN PERMISSION OF THE ENGINEER. THE ENGINEER ASSUMES NO LIABILITY FOR THE DESIGN OR CONSTRUCTION OF THE PROJECT AND DOES NOT WARRANT THE SAFETY AND THE PERFORMANCE OF THE DESIGN OR CONSTRUCTION.



HITE Engineering Corp.
 Consulting Engineers
 2640 Meadowdale Blvd. Unit 2-3
 Mississauga, Ontario L5N 6M6
 1-905-812-3709 F-905-812-3710

INSTALLATION OF CAST-IN-PLACE SAFE-T-STRAP

DRAWN BY:	DATE:
W.I.	1991
SCALE:	ENGINEERING
N.T.S.	R.B.
DRAWING NO:	REV:
14-9479	1

